

Mattel Electronics
1981 Intellivision Point-of-Purchase Display



- | | |
|-------------------|--|
| Dimensions: | 4' wide x 6' tall x 3' deep. Holds a 19" color TV (not included). |
| Color: | Beige top. Walnut grain base. Clear tempered glass doors. Black Pedestal. |
| Storage Area: | 272 cartridges and cassettes. |
| Special Features: | Electronic cartridge selection. Built-in instruction, program guide rolls. Ten-minute gameplay limit. New product/promotion window. 1-year warranty. |

ARMOR BATTLE

(2 Players)

Either player press **SWITCH TANKS** star, then press Disc.

Left Hand Controller runs black tanks; right Controller directs blue. To move your tank, press "**FORWARD**" button on either side of Controller. Tanks only go forward. Steer with Disc, by pressing it in direction you want to go. Aim at an enemy tank. To fire cannon, press "**SHOOT**" button on either side of Controller. Recoil changes aim, and you have to re-aim your tank before firing again.

To change tank you control, press **SWITCH TANKS** star. To lay a mine (once each battle), press **LAY MINE** star. Mine goes off on contact after 5 seconds. Don't blow yourself up!

You move fastest on roads, slower on grass, slowest through woods and water.


3 hits destroy your target tank. When a player's tanks are both knocked out, score appears. To see new battle map, press any control.

KEEP MOVING, USE WOODS & BUILDINGS FOR COVER, SWITCH TANKS TO KEEP ENEMY OFF GUARD!



ARMOR
BATTLE™

© Mattel Inc. 1979.



ARMOR BATTLE

ASTROSMASH


ASTROSMASH

(1 player)

1. Press **DISC**.
2. Use left and right sides of **DISC** to move laser gun. To **FIRE** press either **TOP SIDE BUTTON**; for **RAPID FIRE** hold button in and tap **DISC**.
3. You lose points for every rock that lands. You get a new laser gun when your peak score goes up 1,000 points.

ASTROSMASH™

© Mattel Inc. 1981.



Two full-color
program overlays included with
each game cartridge.


AUTO RACING

(1 or 2 players)

1. Press **DISC**. Select course 1. Press **ENTER**.
2. Select car 1. Press **ENTER**. Press **ENTER** on unused hand controller.
3. Race starts. Press **LEFT SIDE** of **DISC** to steer left; **RIGHT SIDE** to steer right. Use **SIDE BUTTON** to brake.
4. If you **CRASH**, press **SIDE BUTTON** to restart at last checkpoint.

AUTO RACING

©Mattel Inc. 1980



Two full-color
program overlays included with
each game cartridge.

AUTO RACING


BACKGAMMON

(1 or 2 players)

1. Press **DISC**. One player, select **LEVEL 1** (easy) or **LEVEL 2** (advanced). Press **ENTER**. Two players, press **TWO PLAYER**.
2. Computer plays black, you play white. Tap **DISC** to move cursor over piece. To **MOVE**, press **DICE KEY** (1-6) to match rolled dice.
3. Repeat to move next piece. Press **ENTER**.

BACKGAMMON

© Mattel Inc. 1979



SELECT GAME

TWO
PLAYER

LEVEL
1

LEVEL
2

GIVE UP

CLEAR

MOVE
TWO

ENTER

▼ MOVE CURSOR ▼

Two full-color
program overlays included with
each game cartridge.

BACKGAMMON

BASEBALL


BASEBALL

(2 players)

1. Press **DISC**. Right Hand Controller directs Home team, Left Hand directs Visitors.
2. **TO BAT**: Press **TOP SIDE BUTTON** to **HIT**, **BOTTOM SIDE BUTTON** to **BUNT**. Press **RIGHT SIDE OF DISC** after ball is hit to make batter **RUN**.
3. **TO PITCH**: Press **DISC: TOP** for fastball, **SIDES** for inside/outside, **BOTTOM** for change-ups.
4. **TO FIELD**: No fly balls! Press nearest fielder on Keypad, move him to ball with **DISC**. Then press base where throw should go.

BASEBALL

© Mattel Inc. 1979



Two full-color
program overlays included with
each game cartridge.


BASKETBALL

1. Press **RESET** to start. **SELECT** game speed by pressing #3 (slow), #2 (medium), #1 (fast), or **DISC** (fastest). **TEAMS APPEAR.**
2. **RED'S** "controlled player" is **BROWN**, **GREEN'S** is **BLACK.**
3. To **BEGIN GAME**, press **ANY KEY**. **JUMP BALL** occurs. Use your **DISC** to control **PLAYERS.**
4. Keys #1 through #9 are **PASS BUTTONS**, and refer to different areas of the **COURT.**
5. To use **JUMP SHOT** (shoot a basket), press **CLEAR BUTTON**. To **BLOCK**, press #0. To make a **SET SHOT**, press **ENTER BUTTON.**

NBA BASKETBALL

BASKETBALL

© Mattel, Inc. 1979. PRINTED IN U.S.A.




Two full-color
program overlays included with
each game cartridge.

BOWLING

(1 to 4 players)

1. Press **DISC**. Press **5** for Bowling, then **ENTER**.
2. Select number of players (1 to 4). **ENTER**. Press **1** for alley slickness. **ENTER**. Press **3** for 10 lb. ball. **ENTER**. Press **9** for right hand bowler. **ENTER**.
3. Press **DISC** to pick up ball. Move bowler with **LEFT SIDE BUTTONS**. **HOLD LOWER RIGHT SIDE BUTTON IN UNTIL WHITE SPOTTER IS WHERE YOU WANT TO AIM**. Release button to bowl.
4. Before bowler reaches line, press **DISC** to set curve (3 o'clock position least curve, 6 o'clock most).



Two full-color
program overlays included with
each game cartridge.

BOWLING


BOXING

(2 players)

1. Press **DISC**. Each player select boxer (#1-6), then press **ENTER** on both controllers.
2. Press **DISC** to start fight (15 rounds, 1:30 each).
3. Use **DISC** to move fighters, press keys to **PUNCH**, **FEINT**, or **DUCK**.
4. Computer keeps round, fight scores and knockdown clock.

BOXING

© Mattel Inc. 1980



1819-4289-G1

Two full-color
program overlays included with
each game cartridge.

BOXING


CHECKERS

CHECKERS

1. Press **RESET** to start. Press any button to see board. To play **OPPONENT**: press #1. To play **COMPUTER**: press either #2 (you move **FIRST**), or #3 (computer moves **FIRST**.)
2. If **PLAYING COMPUTER**: Select **SKILL LEVEL** by pressing #8 for **LOW SKILL**, or #6 for **HIGH SKILL**.
3. Use **DISC** to move **TAN CURSOR** to man you wish to move. Then press #0 to **PICK UP PIECE**. After moving, press **ENTER**.
4. To **JUMP**, following instructions for a regular move, then press **DISC**. To change a move, press **CLEAR**.
5. When a single man reaches the end of the board (**KING'S ROW**), a dash will appear over it. He is now a **KING**.

CHECKERS


© Mattel, Inc. 1979. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.

CHESS

1. To begin, press **DISC**. You play against **COMPUTER**.
2. Press the edge of the **DISC** to move **CURSOR** from square to square.
3. Use **TOP ACTION BUTTONS** on side of handcontrol to **PICK UP** piece. When you've moved it to desired square, press these buttons again to **PUT DOWN** piece.
4. To **CASTLE**, move **KING** two squares **TOWARD** the **ROOK**. Action is automatic.
5. When a **PAWN** reaches the other side of the board, you can promote the piece by pressing #1, **BISHOP**; #2, **ROOK**; #3, **QUEEN**; #4, **KNIGHT**; or #6, **PAWN**.
6. To **RETRACT A MOVE**, press **LOWER LEFT ACTION BUTTON** on side of handcontrol.



Two full-color
program overlays included with
each game cartridge.

CHESS

FOOTBALL

FOOTBALL

1. Press **RESET** to start. To select **GAME SPEED**, press #3 (slow); #2 (moderate); #1 (fast); or **DISC** (fastest.)
2. At **START**, **BLUE TEAM** is **OFFENSE**. Choose **FORMATION** by press #1 through #9, then **ENTER**.
3. **DEFENSE**: Press #1 through #9 for formation, then **ENTER**.
4. **OFFENSE** presses **TOP ACTION BUTTON** on side of handcontrol to **HIKE**. **ACTION BEGINS**. Control players with **DISC**.
5. **TYPE OF PLAY**: Offense press #7 for **RUNNING**, #8 for **KICK**, or #9 for pass. Then **ENTER**. Use **BOTTOM BUTTON** to coordinate pass with player.

FOOTBALL

© Mattel, Inc. 1979. PRINTED IN U.S.A.

SELECT PLAY

1 	2 	3 
4 	5 	6 
7 	8 	9 
RUN	KICK	PASS

HIKE ▼ PICK ▼

▼ MOVE PLAYER ▼

CLEAR ENTER


Two full-color
program overlays included with
each game cartridge.

FROG BOG

1. To select skill level, press **CLEAR** (easy), **#0** (hard), or **ENTER** (hardest).
2. Press either **#1** for **DAY GAME**, or **#3** for **NIGHT GAME**. (If skill level is easy, **DAY GAME** is automatic.)
3. Press **DISC** to move frog. **CATCH INSECTS** by moving your frog close to them.

FROG BOG

©Mattel, Inc. 1982. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.

FROG BOG

GOLF


(1 to 4 players)

1. Press **DISC**. Select number of players (1 to 4) and press **ENTER**.
2. Select club. Use **DISC** to adjust aim (white bar next to ball).
3. To hit ball, press one of the **SIDE BUTTONS** (long-medium-short).
4. To **HOOK**, press button again **BEFORE** club reaches bottom of swing. To **HIT STRAIGHT**, press again **AT** bottom of swing. To **SLICE**, press **AFTER** bottom of swing.

GOLF

GOLF

© Mattel Inc. 1980.




Two full-color
program overlays included with
each game cartridge.

HOCKEY

(2 players)

1. Press **DISC**. Each player controls one man. **GREEN** player turns **LIGHT BLUE**, **TAN** player turns **DARK BROWN**.
2. To **SKATE WITH PUCK**, press edge of **DISC** in direction you want. To **PASS** or **SHOOT**, use **DISC** to turn man towards intended target, and **HOLD DISC DOWN** while pressing side **PASS** or **SHOOT** buttons.
3. Computer controls both goalies.




Two full-color
program overlays included with
each game cartridge.

HORSERACING

1. Press **RESET** to start. Press **ANY KEY** or **DISC** to see **BETTING SHEET**.
2. Choose a # from 1-6. This will be your player #. **DO NOT ENTER YET. PRESS ANY ACTION BUTTON** on side of hand control. The **COMPUTER** "rides" the upper **TWO HORSES, PLAYERS** ride the lower. When **SIDE BUTTON** is released, **BETTING SHEET** reappears.
3. To **BET**: Key in your player number; press **ENTER**. Key in amount (up to \$250) of bet; press **ENTER**. Then press **ENTER** a final time.
4. Select a **HORSE** by press #1 through #8. Then **ENTER**. When ready to **RACE**, press #0, then **ENTER**.
5. To **COAX** your horse, press **TOP ACTION BUTTON**. To **WHIP** your horse, press **LOWER ACTION BUTTON**.

HORSE RACING

© Mattel, Inc. 1980. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.

LOCK 'N CHASE


LOCK 'N' CHASE

1. To start, press **DISC** when **BLUE DOT** appears on screen.
2. Press #1 on handcontrol, then press **ENTER**.
3. Move thief through maze by using the **DISC**.
4. Lock doors by pressing **ACTION BUTTONS** on left side of handcontrol.

LOCK 'N' CHASE

© 1981, 1982 Data East, Inc.

© Mattel, Inc. 1982. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.


MATH FUN

MATH FUN

1. Press **RESET** to start. Then press **ENTER**. Select # **OF PROBLEMS** (up to 99). For **COLOR LEVEL**, select #1 (easy) through #5 (hardest). For **SKILL LEVEL**, press #1 or #2. Then press **ENTER**. Player #2 now selects **LEVELS**. (If only 1 player, press 0, then **ENTER** on **RIGHT HAND CONTROL**.)
2. **GORILLAS APPEAR**, encountering problems. To **ANSWER**, press correct numbers, then **ENTER**.
3. If **CORRECT**, gorilla remains on banks of river. If **INCORRECT**, gorilla is thrown into river by pressing **ENTER** again. To get back on land, answer correctly.
4. To check answer, press **DISC**. To erase, press **CLEAR**.

MATH FUN

© Mattel, Inc. 1979. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.


NIGHT STALKER

NIGHT STALKER

1. Press **DISC** to start. Select game speed by pressing #1 (slow), #2 (medium), #3 (fast), or **DISC** (fastest).
2. Move **STALKER** through maze by pressing disc. **PICK** up weapons by moving Stalker over them.
3. Press #2 to shoot **STRAIGHT UP**, #4 to shoot **LEFT**, #6 to shoot **RIGHT**, or #8 to shoot straight down.

NIGHT STALKER

© Mattel, Inc. 1982. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.

POKER & BLACKJACK

POKER & BLACKJACK

(1 or 2 players)

1. Press **DISC**. Type in stake (up to \$9999) and press **ENTER**. Press **ENTER** on 2nd controller if only one player.
2. Press game selection (1 to 5).
3. Press **DISC** to see hole card in **POKER**. To bet, type in amount and press **ENTER**. You can **CALL**, **RAISE** or **DROP** in **POKER**; **HIT**, **DOUBLE DOWN**, or **STAND** in **BLACKJACK**.

Las Vegas **Poker & Blackjack**

© Mattel Inc. 1980



SELECT GAME



CLEAR



CALL



ENTER

VIEW CARDS


Two full-color
program overlays included with
each game cartridge.

REVERSI

1. Press **DISC** to start. Press #1 for **EASY** board size, #2 for medium, or #3 for hard.
2. Press #4 for **COMPUTER vs. COMPUTER**, #5 for **YOU vs. COMPUTER**, or #6 for **PLAYER vs. PLAYER**.
3. Select skill level by pressing #7 (easy), #8 (medium), or #9 (hard).
4. **OBJECT:** Turn most of the pieces to your color by bracketing your opponent's in any row (vertically, horizontally, or diagonally).
5. Use **DISC** to move the **CURSOR** to the square you want. To **PLACE** piece, press either **TOP ACTION BUTTON** on side of handcontrol.
6. To **PREVIEW** a move, press either **LOWER ACTION BUTTON**.

REVERSI

© Mattel, Inc. 1981. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.

REVERSI

ROULETTE

1. Press **RESET** to start. **PLAYER ONE** is on the left. Press **DISC** to select **STAKES**. Enter a bet up to \$9,999. Press **ENTER**. If only **ONE PLAYER**, enter 0 on right handcontrol.
2. **PLAYER #1** plays chips that are **LIGHT BLUE**, **PLAYER #2** plays chips that are **GRAY**.
3. Use **DISC** to move chip to place on **ROULETTE BOARD**. When chip is in position, press **NUMBERED KEYS** to indicate amount of your pretend bet (from \$1.00 to \$99.00). Press **ENTER**. Do this for **TWO MORE CHIPS**.
4. Press **LOWER RIGHT ACTION BUTTON** on side of **HAND-CONTROL** to start the roulette wheel spinning.
5. Press either **TOP ACTION KEY** to see wins and losses.
6. To **REPLACE BET**, press **ENTER KEY**, then repeat steps 2 to 4.



Two full-color
program overlays included with
each game cartridge.


ROULETTE

ROYAL DEALER

1. Press **DISC** to start. Select game by pressing the number key for that game. Then press **ENTER**.
2. Select # of players. **ENTER**.
3. To **SELECT** card from your hand, press **DISC** until desired card turns **BLUE**. To **PLAY** a card, press **TOP ACTION BUTTONS** on side of handcontrol. (Also for **DISCARD**.)
4. To **REARRANGE** a card in your hand, press **BOTTOM RIGHT ACTION BUTTON**.
5. In **CRAZY EIGHTS**: To **DRAW** a card, press **BOTTOM RIGHT ACTION BUTTON**. To **REARRANGE**, press **BOTTOM LEFT ACTION BUTTON**. To **DISCARD**, **TOP ACTION BUTTONS**; to **DECLARE A SUIT**, press #5 for Hearts, #7 for Clubs, #9 for Diamonds, #0 for Spades. Then **ENTER**. To **PASS**, press #8.
6. In **RUMMY**: **SIDE ACTION BUTTONS** remain the same. To **TAKE THE UP CARD**, press #1. To **DECLARE GIN**, press #3.
7. **ALL SUIT BUTTONS** remain same in all games.

ROYAL DEALER

© Mattel, Inc. 1982 PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.


SEA BATTLE

SEA BATTLE

1. Press **RESET** to start. Press **ANY BUTTON** to show **STRATEGY MAP**.
2. To make a fleet, press **CLEAR**, then press buttons #1-#9 to create a max. of 3 ships. Then press **ENTER**.
3. Press **DIRECTION DISC** to move fleet toward enemy. Press #0 to stop.
4. When two fleets are in **COMBAT RANGE**, **ENGAGE** in **BATTLE** by pressing #8.
5. To control individual ships, press that ship's button and use **DISC** to steer.
6. To **AIM** your ship, press either **TOP ACTION BUTTON** on side of handcontrol. To **FIRE**, press either **BOTTOM ACTION BUTTON**.

SEA BATTLE

© Mattel, Inc. 1980. PRINTED IN U.S.A.




Two full-color
program overlays included with
each game cartridge.

SKIING

(1 to 6 players)

1. Press **DISC**. Select number of players (1 to 6) and press **ENTER**.
2. Select slope 5. Press **ENTER**. Select course 1. Press **ENTER**.
3. Press **DISC** to start. Press **LEFT SIDE** of **DISC** to steer left, **RIGHT SIDE** to steer right.
4. **JUMP** moguls by pressing either **BOTTOM SIDE BUTTON** just before reaching them.



Two full-color
program overlays included with
each game cartridge.

SKIING


SNAFU

SNAFU

1. Press **RESET** to start. To play **BITE**, press #4, #8, #12, or #16. Press **ENTER**. To play **TRAP**, press any other number up to #15. Press **ENTER**. Select # of **ROUNDS** by pressing #1 to #99. Press **ENTER**.
2. Set **GAME SPEED** by pressing #3 (slow); #2 (medium); #1 (fast); or **DISC** (fastest.)
3. **TRAP GAMES: LEFT CONTROLLER** directs **RED**, **RIGHT CONTROLLER** directs **BLUE**. Press **DISC** to move your **TRAIL** in any direction, trapping your opponent.
4. **BITE GAMES: LEFT CONTROLLER** directs **RED SERPENT**, right **CONTROLLER** directs **BLUE SERPENT**. Use **DISC** to control **SERPENT**. To score, bite off your opponents' serpent's tail.

SNAFU

© Mattel, Inc. 1981. PRINTED IN U.S.A.




Two full-color
program overlays included with
each game cartridge.

SOCCER

(2 players)

1. Press **DISC**. Each player controls one man. **YELLOW** player turns **ORANGE**, **PURPLE** player **BLUE**.
2. To **DRIBBLE**, press edge of **DISC** in direction you want. To **PASS** or **SHOOT**, use **DISC** to turn man towards intended target, and **HOLD DISC DOWN** while pressing side **PASS** or **SHOOT** buttons.
3. Press **GOALIE UP** or **GOALIE DOWN** buttons to defend goal.



Two full-color
program overlays included with
each game cartridge.

SPACE ARMADA


(1 player)

1. Press **DISC**. Press **1**, then press **ENTER**.
2. Use left and right sides of **DISC** to move laser gun. To **FIRE** at descending targets press either **SIDE BUTTON**.
3. Hit the red flying saucer for bonus points and repair of damaged bunker. You get a new laser gun every time you clear the screen.

SPACE ARMADA

SPACE ARMADA™

© Mattel, Inc. 1981.



3759-4289

Two full-color
program overlays included with
each game cartridge.


SPACE BATTLE

1. Press **RESET** to start. Select **GAME SPEED** by pressing #3 (slow); #2 (moderate); #1 (fast); **DISC** (faster); or #4 (fastest). **RADAR SCREEN APPEARS.**
2. Press **ENTER KEY** until **ALIEN SQUADRON** closes to **MOTHER SHIP** (center) turns **PURPLE.**
3. Press #1, #2, or #3 to send your **SQUADRON** to encounter **ALIENS.**
4. When squadron reaches alien, it starts blinking. To **GO TO BATTLE**, press #7 if your squadron is **BLUE**, #8 if **WHITE**, or #9 if **GOLD.** **BATTLE SCREEN** appears.
5. Use **DISC** to move **GUNSIGHT.** Press **ACTION BUTTONS** on side of **HANDCONTROL** to **FIRE** lasers.
6. Return to **RADAR SCREEN** by pressing **CLEAR** button. To **RETURN** your squadron to mother ship, press #4 if squadron is **BLUE**, #5 if **WHITE**, or #6 if **GOLD.**

SPACE BATTLE

SPACE BATTLE

© Mattel, Inc. 1979. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.


SPACE HAWK

SPACE HAWK

1. Press **RESET** to start. Set **GAME SPEED** by pressing #3 (slow); #2 (medium); #1 (fast); or **DISC** (fastest).
2. Press **BOTTOM ACTION BUTTONS** on side of handcontrol to **THRUST** hunter through space. Press **TOP ACTION BUTTONS** to **FIRE** ray gun. Use **DISC** to turn Hunter.
3. Press #1 for **AUTOFIRE**. Press #2 for **SINGLE SHOT**.
4. Press #9 for **HYPERSPACE** (escape hopeless situations).
5. For **DRIFT MODE**, press #4. For **DIRECT** mode, #5. For **SMOOTH** mode, #7. For **QUICK** mode, #8.

SPACE HAWK

© Mattel, Inc. 1981 PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.


SPACE SPARTANS

SPACE SPARTANS

1. Press any **KEY** or **DISC** to start. Press #1 for game speed. **STAR GRID** appears.
2. Press **DISC** to move **CURSOR** to an alien-occupied (black bases) sector. Press any **KEY** to lock your starbase in position. Do this for **THREE** starbases.
3. Move **CURSOR** to alien-occupied sector. Press #5 (hyperdrive), then #7 (on-off) to move ship to that sector. Press **ENTER KEY** to change views.
4. Use **DISC** to move spaceship. Line alien up in your gunsight and press **BUTTONS** on side of handcontroller to **FIRE**.
5. To determine remaining energy, press **CLEAR KEY**. If low return to your star base.
6. To determine number of aliens remaining, press #0.

SPACE SPARTANS

© Mattel, Inc. 1981. PRINTED IN U.S.A.




▼ DIRECTION ▼

Two full-color
program overlays included with
each game cartridge.

STAR STRIKE

1. Press **#3** to **START**. Space Station appears. Use **DISC** to control direction of spaceship.
2. Change spaceship speed by pressing buttons **#1**, **#2**, or **#3**.
3. Use **TOP ACTION BUTTONS** on side of handcontrol to **FIRE** at alien ships.
4. Use **LOWER ACTION BUTTONS** on side of handcontrol to **BOMB** five red targets to save Earth.



Two full-color
program overlays included with
each game cartridge.


STAR STRIKE

SUB HUNT

1. Press **RESET** to start. Select skill level by pressing #3 (easy); #2 (medium); #1 (hard); #4 (harder); #5 (hardest). **SATELLITE MAP** appears.
2. Press **CLEAR BUTTON** to **SELECT SUB**. Use **DISC** to steer it toward enemy **CONVOY**. Repeat with 3 remaining subs.
3. When **CONVOY** and **SUBS** meet, **SONAR MAP** appears. To set **SUB SPEED**: #1, **STOP**; #2, 1/4 speed; #3, 1/2 speed; #4, 3/4 speed; #5, full speed.
4. To **DIVE**, press #7. To **SURFACE**, press #8.
5. Fire **TORPEDOES** by pressing **TOP ACTION BUTTON** on side of handcontrol. **REVERSE ENGINES** by pressing **LOWER ACTION BUTTON**.
6. To **TURN ON/OFF SONAR**, press #9.

SUB HUNT

© Mattel, Inc. 1981. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.


SUB HUNT

TENNIS

1. Press **RESET** to start. Select game speed by pressing #3 (slow); #2 (moderate); #1 (fast); or **DISC** (fastest). **TENNIS COURT** appears.
2. Press #1 to position **SERVER** in **INNER COURT**; #2 for **CENTER**; or #3 for **OUTER**. Press **ANY ACTION BUTTON** on side of handcontrol to **TOSS BALL INTO AIR**. Press **ACTION BUTTON** again to hit ball. (**TOP ACTION BUTTON**: Hard swing, **LOWER ACTION BUTTON**: softer swing).
3. Use **DISC** to move players to receive ball. In returning a stroke, use **TOP ACTION BUTTON** to make a **GROUND STROKE**, and **LOWER ACTION BUTTON** to make a **LOB**.

TENNIS

© Mattel, Inc. 1980. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.


TENNIS

TRIPLE ACTION

1. Press **DISC** to start. Choose **GAME NUMBER**, then press **ENTER**.
2. **BATTLE TANKS**: Choose **OPTION NUMBER** (1, 2, 3, or 4), then press **ENTER**. Press **LOWER ACTION BUTTONS** on side of hand-control to move tank; use **DISC** to steer. Press **TOP ACTION BUTTONS** to **FIRE**.
3. **CAR RACING**: Choose **OPTION NUMBER** (1 or 2), then press **ENTER**. Press **TOP ACTION BUTTONS** to move car forward. Use **DISC** to change lanes. To **BRAKE**, press **LOWER ACTION BUTTONS**.
4. **BIPLANES**: Choose **OPTION NUMBER** (1 or 2), then press **ENTER**. Press **LOWER ACTION BUTTONS** and **TOP EDGE** of **DISC** to **TAKE OFF**. Use **TOP ACTION BUTTONS** to **FIRE** at opponents.

TRIPLE ACTION

© Mattel, Inc. 1981. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.


TRIPLE ACTION

TRON DEADLY DISCS

1. Select **SPEED LEVEL** by pressing #1 (slow); #2 (slower); #3 (slowest). For fastest speed, press **ANY OTHER KEY**.
2. Move **TRON** by pressing **DISC**.
3. Press any numbered key except #5, to **FIRE** Tron's discs in direction you choose. For example, pressing #3, will move disc to Upper Right.
4. Press **DISC** to evade opponents' discs.

TRON DEADLY DISCS

© 1982, Walt Disney Productions.
© Mattel, Inc. 1982. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.

TRON DEADLY DISCS

MAZE-A-TRON

TRON MAZE-A-TRON

1. Select game speed by press #3 (slowest), #2 (medium), #3 (fast), or **DISC** (fastest). Hit any other key than **ENTER** key to begin game.
2. Use **DISC** to move **TRON** through the maze. **RIGHT BOTTOM ACTION BUTTON** on side of handcontrol shields you from red recognizers.
3. To disable the **MASTER CONTROL COMPUTER (MCP)**, change Black 1's (random access memory chips) to black zeros. Use **UPPER ACTION BUTTONS** on side of hand-control to do this. Store them in the Latch (lock-shaped containers).
4. Facing the **MCP**: Pressing **DISC** will move gunsight. Align your sight on the moving numbers, and press **TOP ACTION BUTTON** to fire. Keep the numbers from rolling off the screen.
5. Press **LOWER RIGHT ACTION BUTTON** to shield yourself from **MCP'S** laser eyes.



Two full-color
program overlays included with
each game cartridge.


UTOPIA

1. Press **RESET** to start. Press **ANY NUMBERED KEY** to determine **NUMBER OF ROUNDS** (Term of Office) in game. Press **ENTER**. Press **NUMBERED KEYS** to determine length of round (from 30 to 120 seconds.) Press **ENTER**. Islands appear.
2. You have 100 gold bars to purchase "peace and prosperity" for your people. (# of bars seen on sides of screen). Press #1 to build **FORT**; #2, **FACTORY**; #3, **CROPS**; #4, **SCHOOL**; #5, **HOSPITAL**; #6, **HOUSING PROJECT**; #7, **REBEL SOLDIERS** (on other island); #8, **PT BOAT**; #9, **FISHING BOAT**.
3. Use **DISC** to place **CURSOR** over part of island you wish to build or plant crops, then press appropriate number. (If you don't have enough gold, computer will buzz.)
4. Use **TOP ACTION BUTTONS** on side of handcontrol to see **TOTAL SCORE**. Use **LOWER RIGHT ACTION BUTTON** to display score from previous round. Use **LOWER LEFT ACTION BUTTON** to display island's **POPULATION**.
5. To control **BOATS**, use **DISC** to place **CURSOR** over them, then press #0. Cursor now moves boat, by using **DISC**.

UTOPIA

UTOPIA

© Mattel, Inc. 1981. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.

WORD FUN

1. Press **RESET** to start. Select **GAME SPEED**: press #3 (slow); #2 (moderate); #1 (fast); or **DISC** (fastest.)
2. Select your game by pressing appropriate number.
3. **CROSSWORDS**: Use **DISC** to move **CURSOR**. Press #8 (across) or #9 (down) to indicate direction of word. **SELECT LETTERS** by pressing # beside the letter. After spelling a word, press **ENTER**. Next player presses **ENTER** to begin his turn.
4. **WORD HUNT: (PLAYERS play SIMULTANEOUSLY)** Use **DISC** to move **MONKEYS**. Press **ACTION BUTTONS** on side of handcontrol to **PICK UP LETTERS**. Take letter to **SCORING AREA**, and press **ACTION BUTTON** again to release letter. When you spell a word, press **ENTER**.
5. **WORD ROCKETS**: Move wagon by using **DISC**. Pick a vowel by pressing **ACTION BUTTON**. Line up wagon with floating "space word." Press **ACTION BUTTON** to blast vowel into word.

WORD FUN

© Mattel, Inc. 1980. PRINTED IN U.S.A.



Two full-color
program overlays included with
each game cartridge.

WORD FUN

S/N 5209 Rev-D

MATTEL ELECTRONICS
ADVERTISING DISPLAY NON-ILLUMINATING

MODEL 3806 115VAC 60HZ 10WATTS LISTED

UL 7222

© Mattel Inc. 1981. MADE IN MEXICO 3806-0350

THIS EQUIPMENT COMPLIES WITH THE REQUIREMENTS IN PART 15 OF FCC RULES FOR A CLASS A COMPUTING DEVICE. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA MAY CAUSE UNACCEPTABLE INTERFERENCE TO RADIO AND TV RECEPTION REQUIRING THE OPERATOR TO TAKE WHATEVER STEPS ARE NECESSARY TO CORRECT THE INTERFERENCE.

MATTEL ELECTRONICS Mattel Inc., 3150 Haverland Ave., Hawthorne, CA 90230

VOICE/ DEMO ONLY 1

VOICE CARTRIDGE ONLY 2

CARTRIDGE PLACEMENT

EIGHT CARTRIDGES WITH OR WITHOUT VOICE

3 4 5 6 7 8 9 10



FOR INTELLIVOICE
USE VOICE
CARTRIDGE ONLY

CUSTOMERS
ACCESSIBLE
CARTRIDGE

11

S/N 5209 Rev-D

38

© Mattel, Inc. 1977
MADE IN MEXICO

EQUIPMENT COMPLIES WITH THE REQUIREMENTS IN PART 15 OF FCC
FOR A CLASS A COMPUTING DEVICE. OPERATION OF THIS EQUIPMENT
IN A RESIDENTIAL AREA MAY CAUSE UNACCEPTABLE INTERFERENCE TO
TV RECEPTION REQUIRING THE OPERATOR TO TAKE WHATEVER
NECESSARY TO CORRECT THE INTERFERENCE.

3808-0330

MATTEL ELECTRONICS

Mattel, Inc., 5150 Rosecrans Ave., Hawthorne, CA 90250

CARTRIDGE PLACEMENT

VOICE/
DEMO
ONLY

1

VOICE
CARTRIDGE
ONLY

2

EIGHT CARTRIDGES WITH OR V

3

4

5

6

7



S/N 5209 Rev-D

MATTEL ELECTRONICS®

ADVERTISING DISPLAY, NON-ILLUMINATING

MODEL
3806

115VAC
60HZ
10WATTS

LISTED



722Z

©Mattel, Inc. 1981.

MADE IN MEXICO


3806-0350

CUSTOMERS
ACCESSIBLE
CARTRIDGE



11

FOR INTELLIVOICE
USE VOICE
CARTRIDGE ONLY



MATTTEL ELECTRONICS

Mattel, Inc., 5150 Rosecrans Ave., Hawthorne, CA 90250

CARTRIDGE PLACEMENT

VOICE/
DEMO
ONLY

1

VOICE
CARTRIDGE
ONLY

2

EIGHT CARTRIDGES WITH OR WITHOUT VOICE

3

4

5

6

7

8

9

10

